



NOTE: When connecting the Wiegand Keypad Mullion Reader (WKM900) or the Wiegand Junction Box reader (WJB900), use the cable colours displayed in brackets.

NOTE: Connection details remain the same for all Wiegand models.

NOTE: Distance Between the Registration Interface and the Wiegand Reader **MUST NOT** exceed 150 m (164 yd).



'1' Data (White)

'0' Data (Green)

- Power Input (Black)

+ Power Input (Red)

For Communication distances of up to 10 m (33 ft)

OR

+ 12 V Power Input

- Power Input

Power Supply

For Communication distances of up to 150 m (164 yd)

Used with third-party equipment

Wiegand Connections.jpg

Zapojení čteček Wiegand k registračnímu rozhraní